

Dear SNOAPY,

Thank you for joining the SNOAP club!

By choosing SNOAP you're part of the solution to plastic pollution, cutting your carbon footprint, saving money, and enjoying a wash that's better for you, your family and your pets. Together, we're tackling the 1.8 billion plastic bottles used annually by UK households for hand, hair and body washing.

We're a UK-based, family-run business and truly appreciate your order. You'll receive a review link soon - positive reviews mean the world to us, and you'll earn reward points for each product reviewed - photos & videos are much appreciated, thank you!

Instructions for setting up your dispenser and accessories are included below and overleaf including QR codes to short videos. If you have questions, or need any more information, please email us at info@SNOAP.com.

Quick Tips:

- 1. Ensure the nano-suction tape is only used on clean tile/glass and adheres securely by holding firmly in place for 60 seconds then leave overnight before putting the dispenser on.
- 2. The dispenser door should close easily when loaded check the feeding ring is horizontal if it doesn't.
- 3. Turn the top clockwise to dispense SNOAP and enjoy!

Thank you again, and happy SNOAPING!

AKA Lisa

SNOAP Installation and Usage Instructions

Wall Mounting (see QR code overleaf for video)

- 1. Position the wall mount with enough space above to slide the dispenser in and mark its location.
- 2. Choose between nano-suction tape (for smooth surfaces like glass or tiles not painted walls) or screws (use appropriate fixings, not included).
- 3. If using tape, clean and dry the surface. Apply tape to the back of the wall mount without stretching it, peel off the backing, and press the mount firmly onto the wall for *60 seconds*.
- 4. Wait 24 hours before attaching the dispenser.
- 5. Should you want to remove the wall mount, twist it firmly until it detaches, then remove the tape. Additional tape is available at www.SNOAP.com.

Counter Stand (If Purchased as an Optional Extra)

- 1. Attach the stand arm to the base until it clicks (one-time assembly).
- 2. Stick one of the included nano-dots in each of the 4 round recesses on the underside of the base.
- 3. Remove the white covers from all 4 nano-dots.
- 4. Place the stand on a clean, smooth, dry surface with enough space above to slide the dispenser in. *Press firmly for 60 seconds.*
- 5. Slide the SNOAP dispenser onto the stand (load soaps first for easier setup).
- 6. Wait at least 24 hours before using to allow nano-dots to fully adhere.
- 7. Should you want to move the stand, twist the base firmly to detach, then remove the nano-dots carefully. Nano-dots are reusable and replacements are available at www.SNOAP.com.



Loading and Dispensing SNOAP (see QR code below for video)

- 1. Unlock & open the dispenser door by pushing the latch firmly with your thumb start at the top.
- 2. Ensure the blue legs have finger hold indents at the front. Grip them with your thumb & finger and pull slightly forward to disengage the feeder from the rear threads.
- 3. Slide the feeder up and insert a SNOAP bar, fitting the hole over the centre "stalagmite" on the grating surface.
- 4. Insert a second bar on top of the first, then lower the feeder so the "stalactite" engages the hole in the second bar.
- 5. Push the legs (and top soap) fully back into the unit, ensuring the *feeder is horizontal*.
- 6. Close the door and lock the handle with the latch. *Note: If the door doesn't close easily, the feeder is not level. Pull legs forward and ensure feeder is horizontal, then reinsert do not force closed.
- 7. Turn the handle *clockwise* to dispense SNOAP about ½ turn for a hand wash. Happy SNOAPing!

 *Note: The dispenser can be loaded with one SNOAP bar this is *recommended for high humidity*areas like shower cubicles (clean between use). Turn the handle a few extra times to start dispensing.

All the *hygiene bags* our products are shipped in are cornstarch & fully *biodegradable*.

QR Codes to Instructional Videos



Instructional videos best watched on mobile – each <1min.