

3500258



Please read all instructions carefully before use and retain for future reference.



Protect your hands.



Protect your eyes.



Protect your ears.



Re-tighten fixings every 6 months



CAUTION Potential finger trap/pinchment points



EN

Basic safety precautions should always be followed.

INTENDED USE This product is not intended for outdoor use. This product is not intended as a climbing structure and it is not a toy. Children should be supervised to ensure that they do not play with the product.

BEFORE FIRST USE Locate the product in a suitable area where it will not create an obstruction. Locate away from sources of combustion.

GENERAL SAFETY The assembly pack may contain small parts which can pose a choking hazard to children and pets. Do not overload the product as this may result in damage to the product or personal injury.

CLEANING & MAINTENANCE Do not clean the product with any abrasive cloths or chemicals. Solvents or detergents can cause damage to the surface. Periodically check and re-tighten fittings where applicable. Re-tighten all fittings after first week following assembly. To clean, sponge down with warm water, a soft cloth and mild detergent. Ensure you have all the pieces listed. If you are missing any components, contact our customer services department at support@domu.co.uk



230kg/507lb

Rail Max Weight




1.5kg/3.3lb

Per Bin Max Weight

CONTENT LIST




A: Rail x3



B: Bins x15



D: Wall Screw x12



E: Wall Anchor x12

WALL MOUNTING GUIDE

IMPORTANT When drilling into walls always check that there are no hidden wires or pipes.

Ensure that the screws and wall plugs being used are suitable for supporting the unit to be installed.


If you are unsure it is recommended you contact a suitable qualified tradesperson.

TIPS Ensure you use a recommended drill bit to match the wall plug and hole size.

Take extra care when drilling high walls, ceilings and ceramic tiles, ensure the wall plug is fitted below the ceramic tile to avoid splitting or cracking.


Ensure the wall plugs are well fitted and are a secure fit to the drilled hole.

The guide below will help to determine the most suitable wall plug type for your application.




Shield Anchor

For use with heavier items such as TVs.




Hammer Fixing

Use with wall stuck with plaster board. The Hammer fixing allows it to be fixed to a wall rather than the plaster board.




Cavity Fixing Heavy Duty

For use when supporting heavy loads for example cabinets and shelving.



Cavity Fixing


For use with plaster board partitions or hollow wooden doors.




Standard Wall Plug

Suitable for use on most types of wall such as brick, breeze block, concrete, stone, wood or plaster.


WALL MOUNTING /




- Mark the centre of the four holes onto the Wall
- Marquez le centre des quatre trous sur le mur
- Markieren Sie die Mitte der vier Löcher an der Wand
- Marque el centro de los cuatro agujeros en la pared
- Segna il centro dei quattro fori sul muro



- Drill the marked holes
- Percez les trous marqués
- Bohren Sie die markierten Löcher
- Taladre los agujeros marcados
- Praticare i fori contrassegnati



- Tap the Plastic Anchors into the pre drilled holes.
- Tapez les ancrages en plastique dans les trous pré-perçés.
- Klopfen Sie die Kunststoffanker in die vorgebohrten Löcher.
- Golpee los anclajes de plástico en los orificios perforados previamente.
- Inserire le ancore in plastica nei fori preforati.



- Align the Rail with the holes and insert the screws to secure.

Alignez le rail avec les trous et insérez les vis pour le fixer.

Richten Sie die Schiene an den Löchern aus und setzen Sie die Schrauben ein, um sie zu sichern.

Alinee el riel con los orificios e inserte los tornillos para asegurar.

Allineare la guida con i fori e inserire le viti per fissarla.



EN

DISPOSAL INFORMATION Please recycle where facilities exist. Check with your local authority for recycling advice.

CUSTOMER SERVICE If you are having difficulty using this product and require support, please contact support@domu.co.uk

WARRANTY To register your product and find out if you qualify for a free extended warranty please go to www.vonhaus.com/warranty. Please retain a proof of purchase receipt or statement as proof of the purchase date. The warranty only applies if the product is used solely in the manner indicated in the warnings page of this manual, and all other instructions have been followed accurately. Any abuse of the product or the manner in which it is used will invalidate the warranty. Returned goods will not be accepted unless re-packaged in its original packaging and accompanied by a relevant and completed returns form. This does not affect your statutory rights. No rights are given under this warranty to a person acquiring the appliance second-hand or for commercial or communal use.

COPYRIGHT All material in this instruction manual are copyrighted by DOMU Brands. Any unauthorised use may violate worldwide copyright, trademark, and other laws.

THANK YOU

Thank you for purchasing your product/appliance.
Should you require further assistance with your
purchase, you can contact us at

support@domu.co.uk

VonHaus is a registered trademark of DOMU
Brands Ltd. Made in China for DOMU Brands. M24
2RW.