

3.2L DEHUMIDIFIER WITH AIR PURIFIER



READING AND STORING THE USER MANUAL



Before using this product, please read through this manual carefully paying particular attention to the safety instructions. Failure to do so may result in personal injury or damage to the product.

Carefully save this instruction manual for future reference. Ensure the user manual is included when passing the product on to any third parties.

IMPORTANT SAFETY INSTRUCTIONS FOR PROPER USE

When using electrical appliances, basic safety precautions should always be followed.

Only use the product as described in this user manual. Any other use is considered improper and may result in damage to property or persons. The manufacturer or vendor cannot be held liable for damages or injury incurred through improper or incorrect use.

- Read and familiarise yourself with all operating instructions before using this Dehumidifier.
- Before using your unit into the mains, visually check that the unit is intact and has not suffered any transit damage.
- Check that the voltage indicated on the data plate corresponds with that of the local network before connecting the appliance to the mains power supply.
- Always use this appliance on a solid, level, non-flammable surface.
- The Dehumidifier shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus.
- **DO NOT** immerse the Dehumidifier or its power cord in water or any other liquids.
- DO NOT leave the Dehumidifier unattended during use.
- **DO NOT** leave the Dehumidifier unattended whilst connected to a mains power supply.
- Avoid touching any moving parts within the appliance.



- **DO NOT** insert fingers, pencils or any other objects through the guard.
- DO NOT push objects into any openings as damage to the product and/or electric shock may occur.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Children of less than 3 years should be kept away unless continuously supervised.
- Close supervision is required when using this Dehumidifier near children.
- DO NOT leave this Dehumidifier within reach of children.
- It is imperative to unplug from mains supply after the Dehumidifier has been used, before it is cleaned and whilst being repaired.
- Unplug after each use.
- **DO NOT** operate this appliance if the power cord or plug are damaged. Ensure that the power cord is not stretched or exposed to sharp objects or edges.
- **DO NOT** operate this appliance after a malfunction or after being dropped or damaged in any way.
- **DO NOT** allow the mains cable to hang over sharp edges or come in contact with hot surfaces.
- DO NOT run the mains cable under carpets, rugs, etc.
- Individuals who operate or work in the refrigerant circuit must have the appropriate certification issued by an accredited organization that ensure competence in



handling refrigerants according to a specific evaluation recognized by associations in the industry.

- This product is intended for household use only and should not be used for industrial purposes.
- DO NOT connect the appliance to an electrical outlet using an extension lead. If an outlet is not available, one should be installed by a qualified electrician.
- **DO NOT** use the mains plug or external timer as a means of switching the Dehumidifier on or off. Use the ON/OFF button located on the unit.
- Always place the unit on a dry and stable surface.
- The appliance should not be placed in a laundry or wet room.
- DO NOT position the Dehumidifier close to sources of heat and/or ignition such as radiators, heaters, other electronic equipment, etc.
- No naked flame sources, such as lighted candles, should be placed on the Dehumidifier.
- The appliance must be stored in such a way as to prevent mechanical failure.
- DO NOT use any accessories or attachments with this product other than those supplied or recommended by supplier.
- **DO NOT** use this product for anything other than its intended use.



Explanation of Symbols

The following warning symbols or words are used in this instruction manual:

UK CA

Products labelled with UK Conformity Assessment identifies products conforming to UK statutory requirements.



Products labelled with this symbol conform to applicable provisions of the European Economic Area.



This symbol provides useful additional information on the use of this product.




This symbol identifies that the supply uses an alternating current mains supply.



You should now recycle your waste electrical goods and in doing so help the environment. This symbol means waste electrical products at the end of their useful life should not be disposed of with normal household waste and not sent to landfill. Please ensure it is taken to a suitable facility for disposal. Check with your Local Authority or retailer for recycling advice or visit www.recycle-more.co.uk, enter your postcode to find out your nearest recycling site.



<u>Description of Parts</u>






- 1. Air inlet
- 2. Water Tank
- 3. Power Cable
- 4. Filter Cover
- 5. Air Outlet
- 6. Humidity Display
- 7. Control Panel
- 8. Water level Indicator
- 9. HEPA Filter







- a) Timer Mode
- b) Night Mode
- c) Air Purifier Only
- d) Power On/Off
- e) Humidity Button
- f) Light On/Off



Before the First Use of Your Dehumidifier

Remove all packing materials and discard responsibly. Ensure all parts are present (if applicable) see **Description of Parts**.

Note regarding the Hepa Filter (9)

The **Hepa Filter** (9) is protected by a bag. Remove the packaging from around the **Hepa Filter** (9) before first use



Installation


- Place the unit on a firm, level surface in an area with at least 20cm of free space on all sides to allow for proper air circulation.
- Never install the unit where it could be subject to:
 - 1. Heat sources such as radiators, stoves or other products that produce heat.
 - 2. In an area where oil or water may be splashed.
 - 3. Direct sunlight.
 - 4. Mechanical vibration or shock.
 - 5. Excessive dust.
 - 6. Lack of ventilation, such as cabinet or bookcase.
 - 7. An uneven surface.





Using Your Dehumidifier

1. Insert the mains plug into the nearest available socket.



Switching on Your Dehumidifier

Press the **Power Button** (d) to power the unit up.

The Dehumidifier will power up in Dehumidifier mode.

The **LED Display** (6) will show the current humidity level.

To change the target humidity. Press the **Humidity Button** (e)

Each press of the **Humidity Button** (e) will increase to 5% up to a maximum humidity of 90%.

1 The lowest possible setting of humidity is 30%



Night Mode (b)

To switch your dehumidifier to **night mode** (b) press the night mode button. Switching to **night mode** (b) will reduce the fan speed on the device which will reduce the ambient noise

Switching the Internal Light On/Off (f)

To turn the light off inside of the dehumidifier press the **Light On/Off** (f) Button. To turn the light back on, press the **Light On/Off** (f) button again.

The Colour of the tank light will change depending on the room humidity Red = High humidity, Amber = Medium humidity and Green Low humidity.



Emptying Your Water Tank

When the Water Tank (2) is full, the indicator light will flash, and the dehumidifier

function will switch off automatically.

1. Unplug the Dehumidifer.

2. Grasp the handle at the bottom of the **Water Tank** (2) and pull the tank away from the body of the unit.



3. Pull the top cover off the **Water Tank** (2) and pour away the water.

4. Replace the top cover and push the Water Tank(2) back into the body of the dehumidifier.





Cleaning the Filter


• Always disconnect the Dehumidifier from the mains supply before cleaning.

To clean the filter, gently pull the **Air Outlet** (1) cover away from the body of the Dehumidifier and use a vacuum cleaner to remove any built-up dust or lint. If the filter is badly soiled it can be washed in warm soapy water and a mild detergent. Dry thoroughly before refitting to the unit.



Care and Maintenance of Your Dehumidifier

Do not remove the float from the water tank as this will prevent the unit from starting. Clean the water tank with warm soapy water, do not use harsh abrasive chemicals. Clean the body of the unit with a soft damp cloth.



Using the Timer

- Press the **Timer Button** (a) to enter the timer mode.
- Press the **Timer Button** (a) again to set the time. Each press increase the the number of hours, 8; 12; 24; 36; up to a maximum of 48 hours as displayed.
- Once the time has passed, the Dehumidifier will automatically switch off.
- To cancel the timer at any time, cycle through using the **Timer Button** (a) until the **LED Display** (6) shows 0.

Using the Dehumidifier in Air Purifier Only Mode

- Press the Air Purifier Only Button (c) to use the dehumidifier in Air Purifier only mode. The dehumidifier LED Display (6) will show L2 (High speed).
- Press the Air Purifier Only Button (c) again to decrease the purifier speed. The LED Display (6) will show L1 (Low speed).
- To cancel, press Air Purifier Only Button (c) again and the indicator light will go out, the LED Display (6) will then display the current room humidity again.



Storage

Whilst not in use for long periods, please ensure that you:

- 1. Empty the water tank and wipe away any excess moisture from the tank and body.
- 2. Place the appliance in a cool and dry environment.
- Always disconnect the Dehumidifier from the mains supply before cleaning.
- Clean the water tank with warm soapy water, do not use harsh abrasive chemicals.
- Clean the body of the unit with a soft damp cloth.
- Dry thoroughly before refitting to the unit.

Technical Specification

Model Number	COL1657
Mains Adaptor Rated Input	100-240V~ 50/60Hz
Rated Power	64W
Water Tank Capacity	3.2L
Protection Class (Mains Adaptor)	II
Operating Parameters	10°C-50°C, over 40% RH

Non-Rewireable Mains Plug

If your appliance is supplied with a non-rewireable plug fitted to the mains lead and should the fuse needed replacing, you must use an ASTA approved one (conforming to BS 1362 of the same rating). Never use a plug with the fuse cover missing. If in doubt, consult a qualified electrician.

If you need to remove the plug -DISCONNECT FROM THE MAINS- and then cut it off the mains lead and immediately dispose of it safely. Never attempt to reuse the plug or insert it into a socket outlet as there is a danger of electric shock.

Recycling Information

Disposal of the Packaging

Dispose of paper and cardboard in appropriate paper re-cycling facilities.

Dispose of plastics in the appropriate plastics collection service.

Dispose of non-recyclable plastics in the appropriate plastics collection service.



Disposal of the Product



You should now recycle your waste electrical goods and in doing so help the environment. This symbol means waste electrical products at the end of their useful life should not be disposed of with normal household waste and not sent to landfill. Please ensure it is taken to a suitable facility for disposal. Check with your Local Authority or retailer for recycling advice or visit www.recycle-more.co.uk, enter your postcode to find out your nearest recycling site.

Customer Support

Should you require any product information, replacement parts or accessories, please contact our customer care team on 0161 831 7879 (8.30am-4.30pm Monday to Thursday, 8.00am-4.00pm Friday) and select option 3 or by contacting us via email: help@daewooelectricals.com.

- Replacement parts and accessories are guaranteed for 1 year from the date of purchase.
- It is important to note that your warranty becomes invalid should non Daewoo parts or accessories be used with this appliance.







MIX
Packaging from responsible sources
FSC® C159875



WARRANTY

Thank you for purchasing your Daewoo product.

As part of our commitment to quality, we are offering you an extra 2 years warranty in addition to your 1 year quarantee

Your Daewoo product is guaranteed for 1 year from the date of original purchase, with proof of purchase or receipt. If any defect should occur due to faulty workmanship or material, your faulty product should be returned to the place of purchase, replacement or refund is at the discretion of the retailer.

The guarantee is subject to the following provisions:

- The product must be correctly installed and operated in accordance with the requirements contained in the instruction manual.
- The product must be used solely for domestic purposes. It does not cover general wear and tear, damage, misuse or any consumable parts.
- The guarantee will be rendered invalid if the product is re-sold or has been damaged through inexpert repair.
- The guarantee is only valid within the UK and Eire.

Your standard 1 year guarantee will only be extended to the maximum available for your individual product upon registration. (Note: products must be registered individually and covers the main body and housing). If you do not register your product within 28 days of the original purchase date, your product will only be guaranteed for 1 year.

To validate your extended 2 year warranty*please register your purchase online within 28 days of the original purchase date by registering at:

https://help.daewooelectricals.com Contact Us (daewooelectricals.com)

*Your extended warranty is only valid with proof of purchase receipt and subject to the conditions outlined above.

> Daewoo is a registered trademark. Produced and imported under license by **Eurosonic Group Limited** Brightgate House 1 Brightgate Way Manchester M32 0TB UK EU Rep: EuroSonic Magppie (ESM) Ltd. Ireland D05 X006 www.esgltd.com