


SMART-TECH CLICK SYSTEM

TV Cabinet Assembly Instructions



NOTE

We highly recommend watching the quick help & set up guide video first before assembling. Simply place a smart phone camera over the QR code for a quick link to the video.






















To watch assembly video :
www.frankolsenfurniture.co.uk

Download the **Frank Olsen Smart app** from :
Google Play store or Apple store




HARDWARE



A M3*12  x2	B M3.5*14  x26	C M3.5*18  x20	D M4*25  x4	E  x3	F  x1	G  x1
H  x2	I  x2	J  x4	K  x2	L  x12	M  x4	N  x1
Tools Required-Not Supplied 				O  x4	15  x4	16  x2


PARTS



GUIDE

Assembly Instructions


Ensure dowel is aligned with hole before pushing panel into groove




Disassembly Instructions

Use Disassemble rod 'M' and gently slide in to the small triangle as shown below marked 'KEY'


We highly recommend watching the quick help video before disassembling. Simply place a phone camera over the QR code below for a quick link to the video





1



2




3



4 NOTE : Panels should sit comfortably in position, do not force them, if they do not fit comfortably, they are likely to be UPSIDE down.

Fitting Cam & Dowel panels 6&7


ENSURE Panel 6 has the pre-fitted hinge brackets on the right side of the panel to allow the door to fit correctly. The grey strip on Panel 7 needs to be facing the front of the unit.




* Locate Dowel position first as a guide

5


* Groove on back panel must be this side



6




7



*** Locate Dowel position first as a guide**


8



*** Locate Dowel position first as a guide**



Ensure that cables are not trapped when placing the top panel on (check they are properly hidden in the cable channel)

9




10

PLEASE FOLLOW THE STEPS TO ENSURE NO DAMAGE.
1. Screw in clip 'I' - ensure surface is DUST FREE




11

CAUTION, When peeling off LED adhesive strip, take extra care to peel ONLY the protective strip, not the adhesive strip.




- 2. Do not remove LED strip backing yet. Place LED strip in position under the clip and lay LED strip in place.**
- 3. Start from the CLIP end, remove the LED strip backing with care and place in position on the edge of the back panel pressing firmly.**
- 4. Gently pull the wires so that the end of the LED strip is straight and sticking in position.**

12






13



NOTE : See separate instructions provided on setting up the app / LED strip and Alexa voice control.




14




15






16




17



18




19



20


NOTE: If the push to open mechanism is not working properly, Simply turn the end of the barrel to adjust.




21

Disassembly Instructions

Gently insert Disassembly rod 'M' in to the triangle shown in the diagram as 'KEY' . Once all the way in, the panels will come apart. Due to the click system, the panels may need a gently 'nudge or tap ' to release them.



Insert rod 'M' into each section panel to disassemble panel at a time




We highly recommend watching the quick help video before disassembling. Simply place a phone camera over the QR code below for a quick link to the video



22

Finish - Remove all visible stickers when assembly is fully completed.



CLEANING ADVICE:

To avoid scratching the surfaces, clean only with a non abrasive cleaner.

NOTES ON SETTING UP WIFI

The LEDS lights only work on 2.4 GHz, they will not work on 5.0 GHz

Most homes are 2.4 GHz or operate a dual function. If for any reason the LED lights are not connecting to the app or Alexa, please check the router setting. Most routers will operate both 2.4 and 5.00 GHz so there should be no problem.

In commercial premises, there maybe software to block access connection to unknown apps or services. If this happens, please check with IT Department.

The system will work from a mobile WiFi hotspot from one phone to another. We recommend this approach if there are access issues.

Ensure Bluetooth setting is on.

QUICK HELP GUIDE & TIP VIDEOS

LED LIGHT SET UP GUIDES



Pairing mode



Re-setting pairing mode



AP mode



Re-setting AP mode



Help in setting up Intelligent Eye

Simply hold the camera on a smartphone over the QR code above to go to a quick link to the help video